

CUSTOMERS ARE **REQUIRED** TO CONTACT THE LOCAL POST OFFICE BEFORE INSTALLING THE MAILBOX TO ENSURE ITS CORRECT PLACEMENT AND HEIGHT AT THE STREET. GENERALLY, MAILBOXES ARE INSTALLED AT A HEIGHT OF 41-45 IN. FROM THE ROAD SURFACE TO INSIDE FLOOR OF THE MAILBOX OR POINT OF MAIL ENTRY (LOCKED DESIGNS) AND ARE SET BACK 6-8 IN. FROM FRONT FACE OF CURB OR ROAD EDGE TO THE MAILBOX DOOR.

SE **EXIGE** A LOS CLIENTES DIRIGIRSE A LA OFICINA DE CORREOS LOCAL ANTES DE INSTALAR EL BUZÓN PARA ASEGURAR SU COLOCACIÓN CORRECTA CON RESPECTO A LA ALTURA DE LA CALLE. GENERALMENTE, LOS BUZONES SE INSTALAN A UNA ALTURA DE 41 A 45 PULGADAS (104,1 cm - 114,3 cm) DE LA SUPERFICIE DEL CAMINO HASTA EL FONDO DEL BUZÓN O EL PUNTO DE ENTRADA DE LA CORRESPONDENCIA (DISEÑOS CON SEGURO) Y ESTÁN ALEJADOS 6 A 8 PULGADAS (15,2 A 20,3 cm) DE LA PARTE FRONTAL DE LA CALZADA O EL BORDE DEL CAMINO HASTA LA PUERTA DEL BUZÓN.

## ADJUSTABLE LATCH INSTRUCTIONS INSTRUCCIONES AJUSTABLES DE PICAPORTE

Door catch tension can be adjusted by bending the hook up or down with pliers.  
Ajustar tensión de puerta doblando gancho arriba o abajo con tenazas.

